

Appendix 2

James Russell Concrete - Transfer of Cement to Mixer Truck

1. Ensure that the truck mixer is parked in the correct position - *specific markers on walk platform at plant indicate correct position for each individual truck.
2. Ensure that both aggregate and cement socks have dropped down into the mixer intake hopper, to ensure a minimum fall of materials, to negate release of any dust residue.
3. Run the mixer up to mixing speed, open the aggregate gate and run aggregate flow before starting cement feed screw. Control cement and aggregate feed to ensure even mixing and minimising any dust residue - * always ensure that the cement feed finishes before the aggregate feed to further control any dust emission.